


The product contains one or more of following materials: Wood, metal, plastic.

For more information, please visit **www.efg.info**


Tab S Floor - feet

Assemble the feet with the M6 screws and washers. Use the oval holes to adjust the leveling to the floor. Each screen has four feet.




Foot connections

For connecting screens at different angles, replace the large feet in the corners with either smaller feet or an angled fittings. There are 90° , 120° , T-, X- and straight connections.





Angled bracket fittings, used in <u>inner corners</u> instead of feet. Use the oval holes to adjust the leveling.





Examples, connections

Top connections (optional)

Top connection, fastened with wood screws.

