Rise Frame check

Table doesn't function

Doesn't function or 1 leg doesn't function

Exchange the cables in the controll unit

If both legs move the problem is solved

If both legs are stuck replace the the leg that didn't function at first

Try a reset

Hold both buttons on the hand-controll at the same time for 6 seconds. The table moves down to the lowest position and resets.

Check if the table functions and the problem is solved

No reaction check the electric connections: *Power socket
*Power cable into controll-unit
*Link-cables into the unit
* Link-cables into the Legs
*Handsetcable into Controlunite

Check if the table functions and the problem is solved

Table doesn't function

Look into the controll unit through the phone plug port.
(look for green or blue light)

Green or blue light: check the hand-controll buttons. Loosen the screws on the hand-controll a little

Check if the table functions and the problem is solved

no light: Exchange the control-unit

Table doesn't fuction: Exchange hand-controll and control-unit

Hand-controll

Control-Unit